

SPA EQUIPMENT



PORTABLE STONE HEATER
E-833

AC 120 V • 240 W
4"H x 10"D x 17"W
Holds a maximum of 40 Assorted Stones

 **AMBER PRODUCTS**
inspired spa experiences

SPA EQUIPMENT



PORTABLE STONE HEATER
E-833

AC 120 V • 240 W
4"H x 10"D x 17"W
Holds a maximum of 40 Assorted Stones

 **AMBER PRODUCTS**
inspired spa experiences

IMPORTANT SAFETY INSTRUCTIONS



Amber Products advises all customers to follow basic safety precautions when using electrical equipment. Electrical shock can occur if equipment is used improperly.

1. Do not immerse in water.
2. Always unplug unit before cleaning and handling.
3. Do not remove control switches.
4. Do not pull on cord.
5. Only use proper outlet voltage.
6. Use the Portable Stone Heater for its intended purposes only.
7. Never operate unit if cord or plug is damaged or if the unit has been dropped or is not working properly.
8. Must have water in compartment. See directions.
9. Make sure stones are at proper temperatures before applying.

DIRECTIONS FOR USE

Compact and lightweight, Amber Products Portable Stone Heater has an adjustable temperature thermostat that heats to proper temperature (120 – 200° Fahrenheit) within 15 minutes.

1. Remove heater from package and place on a sturdy surface near an electrical outlet.
2. Fill 1/3 of compartment with water. Add desired amount of stones. Pour additional water on top of stones so that they are completely submerged in water.
Note: Do not heat stones without water in the compartment.
3. Plug in cord and turn on unit. The pilot light will illuminate, indicating that unit is heating.
4. Adjust temperature as required with the thermostat control.
Note: Always test stones for heat prior to placing on client or using for massage.

TO CLEAN: Unplug unit and remove stones. Pour water into sink and wipe clean with a paper towel. To disinfect, use Amber Total Kleen.

WARRANTY INFORMATION

Amber Products prides itself on providing high quality equipment for spas and salons. Each piece of equipment will be covered under the following warranty:

Warranty: 90-day warranty on all equipment from ship date. Product must be shipped back in original packaging or similar quality packaging at customer's expense. Amber will either repair or replace equipment at no charge if found to be manufacture defect. Reports must be made to customer service at 1-800-821-9188. Amber customer service will provide customer with a return authorization (RA) number, which is required for any return to be accepted. Once the RA is given, customer has 15 days to return the product or equipment. Return defective product to: Amber Products, 549 US Route 30, Imperial, PA 15126. Include: Copy of purchase receipt, name, address, contact number and detailed explanation of defect. Upon repair the item will be returned to customer.

NOT COVERED: Failure of equipment due to misuse, abuse, accident, mishandling or neglect.

IMPORTANT SAFETY INSTRUCTIONS



Amber Products advises all customers to follow basic safety precautions when using electrical equipment. Electrical shock can occur if equipment is used improperly.

1. Do not immerse in water.
2. Always unplug unit before cleaning and handling.
3. Do not remove control switches.
4. Do not pull on cord.
5. Only use proper outlet voltage.
6. Use the Portable Stone Heater for its intended purposes only.
7. Never operate unit if cord or plug is damaged or if the unit has been dropped or is not working properly.
8. Must have water in compartment. See directions.
9. Make sure stones are at proper temperatures before applying.

DIRECTIONS FOR USE

Compact and lightweight, Amber Products Portable Stone Heater has an adjustable temperature thermostat that heats to proper temperature (120 – 200° Fahrenheit) within 15 minutes.

1. Remove heater from package and place on a sturdy surface near an electrical outlet.
2. Fill 1/3 of compartment with water. Add desired amount of stones. Pour additional water on top of stones so that they are completely submerged in water.
Note: Do not heat stones without water in the compartment.
3. Plug in cord and turn on unit. The pilot light will illuminate, indicating that unit is heating.
4. Adjust temperature as required with the thermostat control.
Note: Always test stones for heat prior to placing on client or using for massage.

TO CLEAN: Unplug unit and remove stones. Pour water into sink and wipe clean with a paper towel. To disinfect, use Amber Total Kleen.

WARRANTY INFORMATION

Amber Products prides itself on providing high quality equipment for spas and salons. Each piece of equipment will be covered under the following warranty:

Warranty: 90-day warranty on all equipment from ship date. Product must be shipped back in original packaging or similar quality packaging at customer's expense. Amber will either repair or replace equipment at no charge if found to be manufacture defect. Reports must be made to customer service at 1-800-821-9188. Amber customer service will provide customer with a return authorization (RA) number, which is required for any return to be accepted. Once the RA is given, customer has 15 days to return the product or equipment. Return defective product to: Amber Products, 549 US Route 30, Imperial, PA 15126. Include: Copy of purchase receipt, name, address, contact number and detailed explanation of defect. Upon repair the item will be returned to customer.

NOT COVERED: Failure of equipment due to misuse, abuse, accident, mishandling or neglect.